



Drawstring PotSock Tips:

You must ensure the fabric is not touching **ANY PART** of the AQUAvalve5 after the drawstring is cinched tight.



Figure 1- The above picture is showing how your drawstring potsock should appear next to your AQUAvalve

You can use your finger to push the fabric away from the AQUAvalve5. If the fabric is touching the AQUAvalve5, it will disrupt the motion of the top float and can create issues.



Figure 2 - Make sure the drawstring portion of the PotSock is on the opposite end of the AQUAvalve5 as pictured above.